

**SAMSUNG**

# SYSTEM AIR CONDITIONER

Basic : NS070LHXEA&UH070EAV2  
DH070EAV1&UH070EAV2

Model :

NS035LDXEA RC035DHXEA

NS052LDXEA RC052DHXEA

NS071LDXEA RC071DHXEA

NS052SDXEA RC052DHXEA

NS071SDXEA RC071DHXEA

Model Code :

NS035LDXEA RC035DHXEA

NS052LDXEA RC052DHXEA


NS071LDXEA RC071DHXEA

NS052SDXEA RC052DHXEA

NS071SDXEA RC071DHXEA

# ***SERVICE*** Manual

## AIR CONDITIONER



NS035/052/071LDXEA



NS052/071SDXEA



RC035/052DHXEA



RC071DHXEA

## CONTENTS

1. Precautions
2. Product Specifications
3. Disassembly and Reassembly
4. Troubleshooting
5. PCB Diagram and Parts List
6. Wiring Diagram
7. Schematic Diagram
8. Reference Sheet

**Refer to the service manual in the GSPN(see the rear cover) for the more information.**

# Contents

<b>1. Precautions</b>	<b>1-1</b>
1-1 Installing the air conditioner	1-1
1-2 Power supply and circuit breaker	1-1
1-3 During operation	1-2
1-4 Disposing of the unit	1-2
1-5 Others	1-2
<b>2. Product Specifications</b>	<b>2-1</b>
2-1 The Feature of Product	2-1
2-2 Product Specifications	2-2
2-3 The Comparative Specifications of Product	2-7
2-4 Accessory and Option Specifications	2-12
<b>3. Disassembly and Reassembly</b>	<b>3-1</b>
3-1 Indoor Unit	3-2
3-2 Outdoor Unit	3-14
<b>4. Trouble shooting</b>	<b>4-1</b>
4-1 Indoor Display Error and Check Method	4-1
4-2 Outdoor LED Error Display and Check Method	4-4
4-3 Setting Option Setup Method	4-5
4-4 Items to be checked first	4-24
4-5 Fault Diagnosis by Symptom	4-25
4-6 PCB Inspection Method	4-41
4-7 Main Part Inspection Method	4-43
<b>5. PCB Diagram and Parts list</b>	<b>5-1</b>
6-1 Indoor Unit	5-1
6-2 Outdoor Unit	5-2
<b>6. Wiring Diagram</b>	<b>6-1</b>
<b>7. Schematic Diagram</b>	<b>7-1</b>
8-1 Indoor Unit	7-1
8-2 Outdoor Unit	7-2
<b>8. Reference Sheet</b>	<b>8-1</b>
9-1 Refrigerating Cycle Diagram	8-1
9-2 Index for Model Name	8-2

---

# 1. Precautions


---

## 1-1 Installing the air conditioner

---

- Users should not install the air conditioner by themselves.  
Ask the dealer or authorized company to install the air conditioner except the window-type air conditioner in U.S.A and Canada.
- If you don't install the air conditioner properly, it may cause a fire, a water leakage or an electric shock.
- You must install the air conditioner according to the national wiring regulations and safety regulations.
- Install the indoor unit higher than 2.5m from the floor to avoid the injury caused by the operation of the fan. (except the window-type air conditioner)
- The manufacturer is not responsible for any accidents or injury caused by an incorrect installation.

When installing the built-in type air conditioner, keep all electric cables such as the power cable and the connection cord in pipes, ducts, or cable channels to protect them from the danger of impact or any other incidents.




**Avoid Dangerous Contact**

## 1-2 Power supply and circuit breaker

---

- If the power cord of the air conditioner is damaged, it must be replaced by the manufacturer or a qualified person in order to avoid a hazard.
- The air conditioner must be plugged into an independent circuit if applicable or connect the power cable to the auxiliary circuit breaker.  
An all pole disconnection from the power supply must be incorporated in the fixed wiring with a contact opening of >3mm.
- Do not extend an electric cord to the air conditioner.
- The air conditioner must be plugged in after you complete the installation.




**No Tapping and No Extension Cords**

## 1-3 During operation

---

- Do not repair the air conditioner at your discretion.  
It is recommended to contact a service center directly.
- Never spill any kind of liquid on the air conditioner.  
If this happens, turn off the air conditioner and contact an authorized service center.
- Do not insert anything between the airflow blades to prevent damage of the inner fan and consequent injury. Keep children away from the air conditioner.
- Do not place any obstacles in front of the air conditioner.
- Do not spray any kind of liquid into the indoor unit. If this happens, turn off the air conditioner and contact a service center.
- Make sure that the air conditioner is well ventilated at all times:  
Do not place a cloth or other materials over it.
- Remove the batteries if you don't use the remote control for a long time. (If applicable)
- Use the remote control within 7 meters from the indoor unit. (If applicable)



**No children Nearby**

## 1-4 Disposing of the unit

---

- Before throwing out the air conditioner, remove the batteries from the remote control.
- When you dispose of the air conditioner, consult your dealer. If pipes are removed incorrectly, refrigerant may blow out and cause air pollution. When it contacts with your skin, it can cause skin injury.
- The package of the air conditioner should be recycled or disposed of properly for environmental reasons.

## 1-5 Others

---

- Never store or load the air conditioner upside down or sideways to prevent the damage to the compressor.
- Young children or infirm persons should be always supervised when they use the air conditioner.
- Max current is measured according to IEC standard for safety.
- Current is measured according to ISO standard for energy efficiency.

---

## 2. Product Specifications

---

### 2-1 The Feature of Product

---

- **Built-in Cassette Type**

After installed, the air conditioner can be harmonized with a room interior.

- **High Performance & Energy Saving**

With the advanced BLDC inverter technology, it makes a room cool with highly energy saving and arises the efficiency of air conditioner.

- **Long Piping(Length & Height)**

It can give the benefit to the installers and arises the reliability of the air conditioner.

- **Long Ambient Operation(In Low Temperature)**

It can arise the reliability and the capacity of the air conditioner, especially operated in low temperature.

- **Eco-friendly Product(Lead-Free, RoHS, WEEE)**

## 2-2 Product Specifications

Model				Indoor Unit		Outdoor Unit		
				NS035LDXEA		RC035DHXEA		
Performance	Cooling(MIN/STD/MAX)			W		950/ 3500/ 4000		
	Heating(MIN/STD/MAX)			W		720/4000/4600		
	Dehumidifying			ℓ/h		-		
	Air Volume	Cooling		m³/min		-		
		Heating		(H/M/L)		-		
	Noise	Cooling		dB		40		53
		Heating		(H/M/L)		40		53
	Energy Efficiency Ratio	Cooling		W/W		2.81		
		Heating				3.41		
Power			ph/V/Hz		1/220~240V/50Hz			
Power	Power Consumption	Cooling		W		210/ 1245/ 1450		
		Heating				180/ 1173/ 1400		
	Operating Current	Cooling		A		1.6/ 6.0/ 6.6		
		Heating				1.2/ 5.7/ 6.6		
	Power Factor	Cooling		%		70/ 90/ 90		
		Heating				70/ 90/ 90		
Size	Outer Dimension	WidthxHeightxDPTH		mm		900*199*600		790*548*285
				inch		-		-
	Weight(Net)			kg		26		33
	Compressor	Model			G4C090LUDJR			
					Single BLDC			
		Motor	Type		-			
	Rated Output							
	Oil Type				320cc, POE			
	Blower	Type			Blower		Propeller	
SSR					BLDC			
Motor		Type		W		-		-
	Rated Output							
Piping	Pipe O.D Size	Liquid		mm(inch) xL(m)		6.35(1/4)x5		
		Gas		mm(inch) xL(m)		9.53(3/8)x5		
	Connection Method					Flare		
	Between	Height		m		Max. 15		
		Pipe Length		m		Max. 20		
Heat Exchanger				FP1.3*Slit*Slica		FP1.3*G-fin*SILLICA		
Refrigerant Control Unit				EEV				
Freezer Oil Capacitor			cc		-			
Refrigerant to Change(R410A)			g		950			
Protection Device(OLP)				-				
Cooling Test Condition				DB27℃CWB19℃		DB35℃ WB24℃		
Heating Test Condition				DB20℃ WB15℃		DB7℃ WB6℃		

## Product Specifications(cont.)

Model				Indoor Unit		Outdoor Unit		
				NS052LDXEA		RC052DHXEA		
Performance	Cooling(MIN/STD/MAX)			W		1200/ 5000/ 6000		
	Heating(MIN/STD/MAX)			W		700/6000/7000		
	Dehumidifying			ℓ/h		-		
	Air Volume	Cooling		m³/min		-		
		Heating		(H/M/L)		-		
	Noise	Cooling		dB		42		58
		Heating		(H/M/L)		42		58
	Energy Efficiency Ratio	Cooling		W/W		3.23		
		Heating				3.64		
Power			ph/V/Hz		1/220~240V/50Hz			
Power	Power Consumption	Cooling		W		230/ 1550/ 2200		
		Heating				280/ 1650/ 2200		
	Operating Current	Cooling		A		1.3/ 7.0/ 9.8		
		Heating				1.6/ 7.5/ 10.0		
	Power Factor	Cooling		%		95/ 97/ 95		
		Heating				95/ 97/ 95		
Size	Outer Dimension	WidthxHeightxDPTH		mm		1100*199*600		790*548*285
				inch		-		-
	Weight(Net)			kg		31		38.5
	Compressor	Model			UG4T150FUDJQ			
					Twin BLDC			
		Motor	Type		-			
	Rated Output							
	Oil Type				650cc, POE			
	Blower	Type			Blower		Propeller	
SSR					BLDC			
Motor		Type	W		-		-	
	Rated Output							
Piping	Pipe O.D Size	Liquid		mm(inch) xL(m)		6.35(1/4)x5		
		Gas		mm(inch) xL(m)		12.7(1/2)x5		
	Connection Method					Flare		
	Between	Height		m		Max. 20		
		Pipe Length		m		Max. 30		
Heat Exchanger				FP1.3*Slit*Slica		FP1.4*G-fin* Hydrofile		
Refrigerant Control Unit				EEV				
Freezer Oil Capacitor			cc		-			
Refrigerant to Change(R410A)			g		1400 (10g/m)			
Protection Device(OLP)				-				
Cooling Test Condition				DB27℃CWB19℃		DB35℃ WB24℃		
Heating Test Condition				DB20℃ WB15℃		DB7℃ WB6℃		

## Product Specifications(cont.)

Model				Indoor Unit		Outdoor Unit		
				NS071LDXEA		RC071DHXEA		
Performance	Cooling(MIN/STD/MAX)			W		2200/ 7100/ 8000		
	Heating(MIN/STD/MAX)			W		1900/8000/9000		
	Dehumidifying			ℓ/h		-		
	Air Volume	Cooling		m³/min (H/M/L)	9.54/14.2/15.88			
		Heating			11.37/16.87/18.68			
	Noise	Cooling		dB (H/M/L)	44	60		
		Heating			44	60		
	Energy Efficiency Ratio	Cooling		W/W	3.21			
		Heating			3.61			
Power			ph/V/Hz		1/220~240V/50Hz			
Power	Power Consumption	Cooling		W	350/ 2210/ 4000			
		Heating			350/ 2220/ 4000			
	Operating Current	Cooling		A	2/ 10.5/ 21			
		Heating			2/ 10.5/ 21			
	Power Factor	Cooling		%	90.6/ 97.4/ 97.76			
		Heating			92.1/ 97.5/ 97.3			
Size	Outer Dimension	WidthxHeightxDepth		mm	1100*600*199		880X310X798	
				inch	-		-	
	Weight(Net)			kg	32	54.5		
	Compressor	Model			UG4T200FUA4			
					Twin BLDC			
		Motor	Type		8.0μF/450V			
	Rated Output		650cc, POE					
	Blower	Type			Blower		Propeller	
					SSR		BLDC	
Motor		Type	W		30		40	
	Rated Output							
Piping	Pipe O.D Size	Liquid		mm(inch) xL(m)		6.35(1/4)x5		
		Gas		mm(inch) xL(m)		15.88(5/8)x5		
	Connection Method					Flare		
	Between	Height		m		Max.30		
		Pipe Length		m		Max50		
Heat Exchanger				FP1.3*Slit*Slica		FP1.3*Louver		
Refrigerant Control Unit				EEV				
Freezer Oil Capacitor			cc	650				
Refrigerant to Change(R410A)			g	1800(25g/m)				
Protection Device(OLP)				-				
Cooling Test Condition				DB27℃ CWB19℃		DB35℃ WB24℃		
Heating Test Condition				DB20℃ WB15℃		DB7℃ WB6℃		





## Product Specifications(cont.)

Model				Indoor Unit		Outdoor Unit		
				NS052SDXEA		RC052DHXEA		
Performance	Cooling(MIN/STD/MAX)		W	1000/ 5000/ 6000				
	Heating(MIN/STD/MAX)		W	750/ 6000/ 7200				
	Dehumidifying		ℓ/h	-				
	Air Volume	Cooling	m³/min (H/M/L)	-				
		Heating		-				
	Noise	Cooling	dB (H/M/L)	45		58		
		Heating		45		58		
	Energy Efficiency Ratio	Cooling	W/W	3.21				
Heating		3.41						
Power			ph/V/Hz	1/220~240V/50Hz				
Power	Power Consumption	Cooling	W	430/ 1560/ 2200				
		Heating		330/ 1760/ 2300				
	Operating Current	Cooling	A	2.2/7.5/10.0				
		Heating		1.9/8.4/10.0				
	Power Factor	Cooling	%	95/ 97/ 95				
		Heating		95/ 97/ 95				
Size	Outer Dimension	WidthxHeightxDepth		mm	900*260*480		790*548*285	
				inch	-		-	
	Weight(Net)			kg	29.5		38.5	
	Compressor	Model			UG4T150FUDJQ			
		Motor	Type		TWIN BLDC			
			Rated Output		-			
	Oil Type				650cc, POE			
	Blower	Type			Blower		Propeller	
Motor		Type		SSR		BLDC		
		Rated Output	W	-		-		
Piping	Pipe O.D Size	Liquid	mm(inch) xL(m)	6.35(1/4)x5				
		Gas	mm(inch) xL(m)	12.7(1/2)x5				
	Connection Method			Flare				
	Between	Height		m	Max. 20			
		Pipe Length		m	Max. 30			
Heat Exchanger				FP1.3*H-fin*Slica		FP1.4*G-fin,*Hydrofile		
Refrigerant Control Unit				EEV				
Freezer Oil Capacitor			cc	-				
Refrigerant to Change(R410A)			g	1400(10g/m)				
Protection Device(OLP)				-				
Cooling Test Condition				DB27 °CWB19 °C		DB35 °C WB24 °C		
Heating Test Condition				DB20 °C WB15 °C		DB7 °C WB6 °C		




## Product Specifications(cont.)

Model				Indoor Unit		Outdoor Unit	
				NS071SDXEA		RC071DHXEA	
Performance	Cooling(MIN/STD/MAX)			W	2200/ 7100/ 8000		
	Heating(MIN/STD/MAX)			W	1900/ 8000/ 9000		
	Dehumidifying			ℓ/h	-		
	Air Volume	Cooling	m <sup>3</sup> /min (H/M/L)	17.86/19.84/20.65			
		Heating		15.27/20.03/22.48			
	Noise	Cooling	dB (H/M/L)	45	60		
		Heating		45	60		
	Energy Efficiency Ratio	Cooling	W/W	3.21			
		Heating		3.61			
Power			ph/V/Hz	1/220~240V/50Hz			
Power	Power Consumption	Cooling	W	350/ 2210/ 4000			
		Heating		350/ 2220/ 4000			
	Operating Current	Cooling	A	2/10.5/21.0			
		Heating		2/10.5/21.0			
	Power Factor	Cooling	%	90.2/ 97/ 97.3			
		Heating		90.3/ 97.2/ 97.6			
Size	Outer Dimension	WidthxHeightxD		mm	1150*480*260		880X310X798
				inch	-		-
	Weight(Net)			kg	33		54.5
	Compressor	Model			UG4T200FUA4		
					TWIN BLDC		
		Motor	Type	8.0μF/450V			
	Rated Output		650cc, POE				
	Oil Type				650cc, POE		
		Blower	Type			Blower	Propeller
Motor			Type		SSR	BLDC	
			Rated Output	W	30	40	
Piping	Pipe O.D Size	Liquid	mm(inch) xL(m)	6.35(1/4)x5			
		Gas	mm(inch) xL(m)	15.88(5/8)x5			
	Connection Method			Flare			
	Between	Height	m	Max.30			
		Pipe Length	m	Max50			
Heat Exerchanger				FP1.3*Slit*Slica		FP1.3*Louver	
Refrigerant Control Unit				EEV			
Freezer Oil Capacitor			cc	650			
Refrigerant to Change(R410A)			g	1800(25g/m)			
Protection Device(OLP)				-			
Cooling Test Condition				DB27℃WB19℃		DB35℃WB24℃	
Heating Test Condition				DB20℃WB15℃		DB7℃WB6℃	


## 2-3 The Comparative Specifications of Product

Item		NS035LDXEA/RC035DHXEA	NS035LHXEA/UH035EAV1(Basic)
Design	Indoor Unit		
	Outdoor Unit		
Net Weight	Indoor Unit	26.0kg	22.0kg
	Outdoor Unit	33.0kg	50.0kg
Outer Dimension (WxHxD)	Indoor Unit	990x199x600mm	990x199x600mm
	Outdoor Unit	790x548x285mm	790x548x285mm
Noise	Indoor Unit	40dB↓	40dB↓
	Outdoor Unit	53dB↓	53dB↓


## The Comparative Specifications of Product(cont.)

Item		NS052LDXEA/RC052DHXEA	NS052LHXEA/UH052EAV1(Basic)
Design	Indoor Unit		
	Outdoor Unit		
Net Weight	Indoor Unit	26.0kg	26.0kg
	Outdoor Unit	33.0kg	50.0kg
Outer Dimension (WxHtxD)	Indoor Unit	990x199x600mm	990x199x600mm
	Outdoor Unit	790x548x285mm	790x548x285mm
Noise	Indoor Unit	42dB↓	42dB↓
	Outdoor Unit	58dB↓	58dB↓



## The Comparative Specifications of Product(cont.)

Item		NS071LDXEA/RC071DHXEA	NS071LHXEA/UH071EAV2(Basic)
Design	Indoor Unit		
	Outdoor Unit		
Net Weight	Indoor Unit	32.0kg	32.0kg
	Outdoor Unit	54.5kg	54.5kg
Outer Dimension (WxHtxD)	Indoor Unit	1100x600x199mm	1100x600x199mm
	Outdoor Unit	880x310x798mm	880x310x798mm
Noise	Indoor Unit	44dB↓	44dB↓
	Outdoor Unit	60dB↓	60dB↓






## The Comparative Specifications of Product(cont.)

Item		NS052SDXEA/RC052DHXEA	DH052EAV1/UH052EAV1(Basic)
Design	Indoor Unit		
	Outdoor Unit		
Net Weight	Indoor Unit	29.5kg	29.5kg
	Outdoor Unit	38.5kg	38.5kg
Outer Dimension (WxHxD)	Indoor Unit	900*260*480 mm	900*260*480mm
	Outdoor Unit	790x548x285mm	790x548x285mm
Noise	Indoor Unit	45dB↓	45dB↓
	Outdoor Unit	58dB↓	58dB↓

## The Comparative Specifications of Product(cont.)

Item		NS071CDXEA/RC071DHXEA	DH070EAV1/UH070EAV2(Basic)
Design	Indoor Unit		
	Outdoor Unit		
Net Weight	Indoor Unit	33.0kg	33.0kg
	Outdoor Unit	54.5kg	54.5kg
Outer Dimension (WxHtxD)	Indoor Unit	1150*480*260mm	1150*480*260mm
	Outdoor Unit	880*310*798mm	880*310*798mm
Noise	Indoor Unit	45dB↓	45dB↓
	Outdoor Unit	60dB↓	60dB↓

## 2-4 Accessory and Specifications

Item	Descriptions	Code-No.	Q'TY	Remark
	Wired remote controller	DB97-15070D	1	Indoor Unit
	Owner's Manual	DB98-32657A	1	
	Installation Manual	DB98-32737A	1	
	Insulation	DB62-04318S	1	
	Insu Drain Hose	DB62-11028A	1	
	Insu Hose	DB62-11208E	1	
		DB62-11208D	1	
	Cable Tie	DB65-10088C	8	
	Grommet Hanger	DB63-00237A	8	
	Ass'y Drain Hose Joint	DB94-03287A	1	
	RUBBER LEG	DB73-20134A	4	Outdoor unit
	DRAIN PLUG	DB67-20011A	1	
	INSTALLATION MANUAL	DB98-34367A	1	

### 3. Disassembly and Reassembly

#### ■ Necessary Tools

Item	Remark
+SCREW DRIVER	
MONKEY SPANNER	






## 3-1 Indoor Unit

Stop operation of the air conditioner and remove the power cord before repairing the unit.






### ■ NS035/052/071LDXEA






No	Parts	Procedure	Remark
1	Filter	<p>1) Pull out the Filter as picture 1 or picture 2.</p> <p>2) If it is necessary, after disassembling 8 indicating screws, detach the Bracket Filter.</p>	   



No	Parts	Procedure	Remark
		<p>3) If the Cabinet-Top Motor is assembled on the side of the set, the procedure of disassembling the Filter is just as the above.</p>	
2	Blower & Motor	<p>1) After disassembling 13 indicating screws, detach Ass'y Cabinet-Top Motor.</p> <p>2) After disassembling 3 indicating screws, detach Ass'y Case Blower Upper.</p> <p>– Press the pothook of the Case Blower and detach Ass'y Case Blower Upper.</p>	

No	Parts	Procedure	Remark
		<p>3) After disassembling 2 indicating screws, detach the Cover Control.</p> <p>4) Detach the Motor Wire Connected to PCB and Capacitor.</p> <p>5) After disassembling the indicating screws, detach the wire connected to the Partition.</p> <p>6) After disassembling 2 indicating screws, detach the Ass'y Band Motor.</p>	    





No	Parts	Procedure	Remark
		7) After disassembling the Motor and Blowers, detach the Blowers from the axis of the Motor by 3mm inner hexagon spanner.	
3	Drain Pan	<p>1) After disassembling 15 indicating screws, detach Ass'y Cabinet-Top Evap.</p> <p>2) After disassembling 6 indicating screws, detach the Bracket Outlet.</p> <p>3) Detach the Drain Pan.</p>	  




No	Parts	Procedure	Remark
4	Evaporator	<p>* After finished the procedures above, detach the Evaporator.</p> <p>1) After disassembling 2 indicating screws, detach Ass'y Cover Pipe.</p> <p>2) Detach the Sensor from the Control Box.(including 2 Sensors)</p> <p>3) After disassembling 2 indicating screws, detach Ass'y Support Evap LF.</p> <p>4) After disassembling 2 indicating screws, detach Ass'y Support Evap RH.</p>	    



No	Parts	Procedure	Remark
		5) Detach the Evaporator from the set.	
5	Control In	<p>* Detach the parts of Control In after disassembling the Cover Control.</p> <p>1) Detach all the wires connected to the PCB.</p> <p>2) If only the disassembly of PCB required, press the Pothook and detach the PCB from the set.</p> <p>3) If only the disassembly of Capacitor is required, detach it from the set.</p> <p>4) If only the disassembly of Case Control is required, detach it from the set after disassembling 2 indicating screws.</p>	   





No	Parts	Procedure	Remark
		5) Detach the Transformer after disassembling 2 indicating screws. * Work is possible after disassembling the Case PCB.	
6	Ass'y Bracket Outlet	1) After disassembling 16 indicating screws, detach Ass'y Bracket Outlet.	





## ■ NS052/071SDXEA

No	Parts	Procedure	Remark
1	Blower & Motor	<p>1) After disassembling 16 places indicating screws, detach Ass'y Cabi Bottom Blower.</p> <p>2) Detach from Ass'y Control In the capacitor connection wire between the Motor Fan and housing connector.</p> <p>3) After disassembling 2 places indicating screws, detach the 2 Fan Case.</p>	   

No	Parts	Procedure	Remark
		4) After disassembling 2 places indicating screws, detach Fan Motor and Blower from the set.	
2	Control In	<p>1) After disassembling 1 Indicating screw, detach the Cover control.</p> <p>2) Detach the Motor-Fan and Sensor Connector from the PCB.</p>	  





No	Parts	Procedure	Remark
		3) Disassemble 4 indicating screws and detach Control In from the set.	
3	Drain Pan	<p>Work is possible when Disassembling the Ass'y Cabi Bottom Blower.</p> 1) Disassemble 7 indicating screws and detach Ass'y Cabi Bottom Drain.	





No	Parts	Procedure	Remark
		<p>2) Disassemble 4 indicating screws and detach the Drain Pan. (2 screws each at left and right side)</p>	  
4	Evap	<p>Work is possible when Disassembling the Ass'y Drain Pan.</p> <p>1) Disassemble 5 indicating screws to detach Cover Pipe.</p>	




No	Parts	Procedure	Remark
		<p>2) Disassemble Sensor on the Evap.</p> <p>3) Disassemble 4 indicating screws which are in the near of Hanger Plate to detach the Evap. (2 screws each at left and right side)</p> <p><b>⚠</b> It needs 2 peoples.</p>	   






3-2 Outdoor Unit





■ RC071DHXEA




No	Parts	Procedure	Remark
1	Common Work	<div>1) Loosen 1 fixing screw of the Cover-Control and detach the Cover Control.</div> <div>2) Loosen each 7 fixing screws and detach the Cabinet Upper.</div>	<div></div> <div></div> <div></div> <div></div> <div></div>

No	Parts	Procedure	Remark
		<p>3) Loosen 2 screws fixed to assemble Control Box with Cabinet-Side RH.</p> <p>4) Loosen fixing screws and detach the Cabinet-Side RH.</p> <p>5) Loosen 2 screws fixed on the Guide Condenser.</p>	   






No	Parts	Procedure	Remark
		6) Loosen fixing screws of the Cabinet Front.	   




No	Parts	Procedure	Remark
3	ASS'Y Control Out	<ol style="list-style-type: none"> <li>1) Detach several connectors from the ASS'Y Control Out.</li> <li>2) Detach several connectors from the PCB of ASS'Y Control Out.</li> <li>3) Pull up the ASS'Y Control Out.</li> </ol>	  
4	Heat Exchanger	<ol style="list-style-type: none"> <li>1) Release the refrigerant at first.</li> <li>2) Loosen fixing screw on both sides.</li> <li>3) Disassemble the pipes in both inlet and outlet with welding torch.</li> <li>4) Detach the Heat Exchanger.</li> <li>5) Loosen 4 bolts fixed to assemble Valve Service with Bracket Valve like the picture on the right side.</li> </ol>	 




No	Parts	Procedure	Remark
2	Fan & Motor	<p>1) Detach the Nut Flange like the picture on the right side. (Turn counter clockwise because the screw is right-handed.)</p> <p>2) Detach the Fan Propeller.</p> <p>3) Loosen 4 fixing screws to detach the Motor.</p> <p>4) Disconnect the wire between ASS'Y Control Out and Motor.</p> <p>5) Loosen 2 fixing bolts and detach the Bracket Motor.</p>	   





No	Parts	Procedure	Remark
5	Compressor	<p>1) Loosen the fixing nut and detach the Compressor Lead Wire.</p> <p>2) Disassemble the Felt Compressor Sound.</p> <p>3) Loosen the 3 bolts at the bottom of Compressor like the picture on the right side.</p>	  

## ■ RC026DHXEA/ RC035DHXEA/ RC052DHXEA

No	Parts	Procedure	Remark
1	common work	<p>1) loosen 1 pcs screw of cover control, and detach it.</p> <p>2) loosen 5 pcs screws on both right and left cabinet side edges and to detach the cover-top</p> <p>3) Loosen 7 screws fixed to disassemble cabi-front , and detach it.</p>	    

No	Parts	Procedure	Remark
	common work	<p>4) loosen 7 screws to disassemble the cabi-right ,and detach it.</p> <p>5) loosen 2 screws to disassemble steel-bar.</p> <p>6) loosen 3 screws to disassemble cabi-left.</p>	   

No	Parts	Procedure	Remark
2	fan&motor	<p>1) loosen 1 screw as indication and detached the fan.</p> <p>2) loosen 4 pcs motor screws and disconnect the wire between assy control out and motor.</p> <p>3) loosen 2 pcs bracket-motor screw and detach it.</p>	  

No	Parts	Procedure	Remark
3	assy control out	1) loosen fixing 1 screw from cover -control 2) detach several connections from assy control out, take out assy control out.	  
4	Heat exchanger	1) Release the refrigerant at first 2) Loosen fixing screw on both side. 3) disassembly the pipes in both inlet and outlet with welding torch. 4) detach the heat exchanger.	



## 4. Troubleshooting

### 4-1 Indoor Display Error and Check Method

#### ■ Error detection and reoperation

- ◆ If error occurs during the operation, badness is indicated by LED flickering and all operation is stopped except LED.
- ◆ When reoperating by remote control and switch determine the error mode after normal operation.


#### ■ Indoor unit LED lamp display at error detecting

Error type	LED lamp display					Remarks
	Operation	Defrost	Timer	Air flow	Filter	
Power reset	●	X	X	X	X	
Error of temperature sensor in the indoor unit(Open/Short)	X	X	●	X	X	
Error of heat exchanger sensor in the indoor unit	●	X	●	X	X	
Error of the outdoor temperature sensor Error of the condensor temperature sensor Error of the discharge temperature sensor	●	X	X	●	X	
1. No communication for 2 minutes between indoor units (Communication error for more than 2 minutes) 2. Indoor unit receiving the communication error from outdoor unit 3. Outdoor unit tracking 3 minutes error 4. When sending the communication error from the outdoor unit, the mismatching of the communication numbers and installed numbers after completion of tracking (Communication error for more than 2 minutes)	X	X	●	●	X	
1. Error of electronic expansion valve close 2. Error of electronic expansion valve open 3. 2'nd detection of high temperature cond 4. 2'nd detection of high temperature discharge 5. Error of reverse phase 6. Compressor down due to 6'th detection of freezing	X	X	●	●	●	
Detection of the float switch	X	X	X	●	●	
Error of setting option switches for optional accessories	X	X	●	X	●	
EEPROM option error	●	●	●	●	●	

● : On, ● : Flickering, X: OFF

※ If you turn off the air conditioner when the LED is flickering, the LED is also turned off.

## ■ Wired Remocon Error Display

- If an error occurs,  is displayed on the wired remote controller.  
If you would like to see an error code, press the Test button.

Display	Explanation	Remark
<b>808</b>	Indoor unit Communication Error	Communication Error
<b>802</b>	Indoor/Outdoor unit Communication Time Out Error 60 Packet Over data	
<b>208</b>	Indoor unit is not connected	
<b>203</b>	Communication Error between Outdoor Main and Inverter Micom (Occurred after 1 minute detection in Main and Inverter)	
<b>828</b>	Indoor Temp. Sensor(Open/Short Error)	Indoor Sensor Error
<b>822</b>	Indoor Unit Eva in Sensor(Open/Short Error)	
<b>828</b>	Indoor Unit Eva in Sensor Separation	
<b>228</b>	Outdoor Temp. Sensor Error(Open/Short Error)	Outdoor Sensor Error
<b>238</b>	COND Temp. Sensor Error(Open/Short Error)	
<b>258</b>	Inverter Compressor Discharge Temp. sensor Error(Open/Short Error)	
<b>425</b>	Power cable miss connection error	
<b>853</b>	Indoor Float Switch 2nd Detection	Self Diagnosys Error
<b>460</b>	Outdoor unit - indoor unit communication wire miss connection (Connected to Power terminal)	
<b>554</b>	Outdoor unit refrigerant Full leakage(Gas leak)	
<b>458</b>	Outdoor Fan 1 Error	
<b>405</b>	Outdoor Fan 2 Error	
<b>406</b>	Discharge over temperature	Outdoor Unit Protetion Control Error
<b>461</b>	[Inverter] Compressor starting error	
<b>462</b>	Primary Current Over Trip error	
<b>464</b>	[Inverter]IPM Over Current(O.C)	
<b>467</b>	[Inverter] Compressor Rotation error	
<b>468</b>	[Inverter] Current Sensor error	
<b>469</b>	[Inverter] DC LINK Sensor error	
<b>408</b>	[Inverter] EEPROM Read/Write Error	

Display	Explanation	Remark
<b>404</b>	[Inverter] Heatsink temperature over Error	Outdoor Unit Protection Control Error
<b>556</b>	Outdoor unit Capacity Setup option error	
<b>601</b>	Communication error between Indoor unit and wired remote control	Wired remote control error
<b>602</b>	Communication error between Master and Slave wired remote control	
<b>606</b>	COM1/COM2 Cross-installed error	
<b>8EA</b>	Error of setting option for wired remote control COM2	

## 4-2 Outdoor Unit Error Display

If an error occurs during the operation, it is displayed on the outdoor unit PCB LED, both MAIN PCB and INVERTER PCB.



No.	Error Code	Meaning	Remarks
1	<b>E201</b>	Unit quantity miss matching between indoor and outdoor.	Check indoor quantity setting in outdoor (Refer to page 17.)
2	<b>E202</b>	Abnormal state, no communication between Indoor and Outdoor Main PCB	Check electrical connection and setting
3	<b>E203</b>	1min. Time out of communication error(Main↔ Inverter)	Check electrical connection and setting
4	<b>E221</b>	Outdoor temp sensor error	Check Outdoor sensor Open/Short
5	<b>E231</b>	Cond. temp sensor error	Check Cond. sensor Open/Short
6	<b>E251</b>	Discharge temp sensor error	Check Discharge sensor Open/Short
7	<b>E320</b>	OLP Sensor Error	Check OLP sensor Open/Short
8	<b>E403</b>	Detection of Outdoor Freezing when Comp. Stop	Check Outdoor Cond.
9	<b>E404</b>	Protection of Outdoor Overload when Comp. Stop	Check Comp. when it start
10	<b>E416</b>	Discharge temperature of a compressor in an outdoor unit is overheated.	
11	<b>E440</b>	Heating operation is not available since the outdoor air temperature is over 30°C.	Heating
	<b>E441</b>	Cooling operation is not available since the outdoor air temperature is lower than -5°C.	Cooling
12	<b>E458</b>	Outdoor unit BLDC Fan 1 or Fan 2 error	FAN1 error
	<b>E475</b>		FAN2 error
13	<b>E461</b>	Comp. Starting error	
14	<b>E462</b>	Primary Current Trip error	
15	<b>E463</b>	Over current trip / PFC over current error	Check OLP sensor
16	<b>E464</b>	IPM(IGBT Module) Over Current(O.C)	
17	<b>E465</b>	Comp. Over load error	
18	<b>E466</b>	DC-Link voltage under/over error	Check AC Power or DC_Link voltage
19	<b>E467</b>	Comp. wire missing error	Check Comp. wire
20	<b>E468</b>	Current sensor error	Check Outdoor Inverter PBA
21	<b>E471</b>	Outdoor EEPROM error	Check Outdoor EEPROM date
22	<b>E474</b>	IPM(IGBT Module) or PFCM Temperature sensor Error	Check Outdoor Inverter PBA
23	<b>E484</b>	PFC Overload Error	Check Outdoor Inverter PBA
24	<b>E500</b>	IPM is over heated.	Check Outdoor Inverter PBA
25	<b>E554</b>	GAS Leak error	Check indoor and outdoor unit model
26	<b>E556</b>	Capacity miss match between indoor and outdoor	Check indoor and outdoor unit model


## 4-3 Setting Option Setup Method

### 4-3-1 Type A (Setting Option)


Option No. : 045770 - 128000



#### Step 1 : Enter the Option Setup mode.
















- 1<sup>st</sup> Take out the batteries of remote control.
- 2<sup>nd</sup> Press the temperature  button simultaneously and insert the battery again.
- 3<sup>rd</sup> Make sure the remote display shown as .




#### Step 2 : Enter the Option Setup mode and select your option according to the following procedure.



S Setting is not required if you must  a value which has a  default.

- 1  
The default value is .  
Otherwise, push the  button to .  
Every time you push the button, the display panel reads 1 or  repeatedly.
- 2  
Push the  button to set the display panel to 4.  
Every time you push the button, the display panel reads  → 1 → 2 → 3 → ... 9 → A → b → c → d → E → F repeatedly.
- 3  
Push the  button to set the display panel to 5.  
Every time you push the button, the display panel reads  → 1 → 2 → 3 → ... 9 → A → b → c → d → E → F repeatedly.
- 4  
Push the  button to set the display panel to 7.  
Every time you push the button, the display panel reads  → 1 → 2 → 3 → ... 9 → A → b → c → d → E → F repeatedly.
- 5  
Push the  button to set the display panel to 7.  
Every time you push the button, the display panel reads  → 1 → 2 → 3 → ... 9 → A → b → c → d → E → F repeatedly.
- 6  
Push the  button to set the display panel to .  
Every time you push the button, the display panel reads  → 1 → 2 → 3 → ... 9 → A → b → c → d → E → F repeatedly.



Setting is not required if you must a value which has a default.

7

Press **Mode** button, then the default value is  $\begin{matrix} 12 \\ 88 \\ 88 \end{matrix}$ .

8

Push the **Up** button to set the display panel to  $\begin{matrix} 12 \\ 88 \\ 88 \end{matrix}$ .  
Every time you push the button, the display panel reads  $0 \Rightarrow 1 \Rightarrow 2 \Rightarrow 3 \Rightarrow \dots 9 \Rightarrow A \Rightarrow b \Rightarrow c \Rightarrow d \Rightarrow E \Rightarrow F$  repeatedly.

9

Push the **Down** button to set the display panel to  $\begin{matrix} 12 \\ 88 \\ 88 \end{matrix}$ .  
Every time you push the button, the display panel reads  $0 \Rightarrow 1 \Rightarrow 2 \Rightarrow 3 \Rightarrow \dots 9 \Rightarrow A \Rightarrow b \Rightarrow c \Rightarrow d \Rightarrow E \Rightarrow F$  repeatedly.

10

Push the **Filter Reset** button to set the display panel to  $\begin{matrix} 12 \\ 88 \\ 88 \end{matrix}$ .  
Every time you push the button, the display panel reads  $0 \Rightarrow 1 \Rightarrow 2 \Rightarrow 3 \Rightarrow \dots 9 \Rightarrow A \Rightarrow b \Rightarrow c \Rightarrow d \Rightarrow E \Rightarrow F$  repeatedly.

11

Push the **On Timer** button to set the display panel to  $\begin{matrix} 12 \\ 88 \\ 88 \end{matrix}$ .  
Every time you push the button, the display panel reads  $0 \Rightarrow 1 \Rightarrow 2 \Rightarrow 3 \Rightarrow \dots 9 \Rightarrow A \Rightarrow b \Rightarrow c \Rightarrow d \Rightarrow E \Rightarrow F$  repeatedly.

12

Push the **Off Timer** button to set the display panel to  $\begin{matrix} 12 \\ 88 \\ 88 \end{matrix}$ .  
Every time you push the button, the display panel reads  $0 \Rightarrow 1 \Rightarrow 2 \Rightarrow 3 \Rightarrow \dots 9 \Rightarrow A \Rightarrow b \Rightarrow c \Rightarrow d \Rightarrow E \Rightarrow F$  repeatedly.

### Step 3 : Upon completion of the selection, check you made right selections.


Press the Mode Selection key, **Mode** to set the display part to  $\begin{matrix} 12 \\ 88 \\ 88 \end{matrix}$  and check the display part.

→ The display part shows  $\begin{matrix} 12 \\ 88 \\ 88 \end{matrix}$ .

Press the Mode Selection key, **Mode** set the display part to  $\begin{matrix} 12 \\ 88 \\ 88 \end{matrix}$  and check the display part.

→ The display part shows  $\begin{matrix} 12 \\ 88 \\ 88 \end{matrix}$ .


### Step 4 : Pressing the ON/OFF button( )

When pressing the operation ON/OFF key with the direction of remote control for unit, the sound "Ding" or "Diriring" is heard and the OPERATION ICON(  ) lamp of the display is flickering at the same time, then the input of option is completed. (If the diriring sound isn't heard, try again pressing the ON/OFF button.)

### Step 5 : Unit operation test-run

**First**, Remove the battery from the remote control.







**Second**, Re-insert the battery into the remote control.







**Third**, Press ON/OFF button(  ) with the direction of remote control for set.







#### • Error Mode







- 1<sup>st</sup> If all lamps of indoor unit are flickering, Plug out, plug in power plug again and press ON/OFF key to retry.
- 2<sup>nd</sup> If the unit is not working properly or all lamps are continuously flickering after setting the option code, see if the correct option code is set up for its model.




## 4-3-2 Type B( Setting Option Setup Method)







Operation method	Applicable button	Indicating state
<p>※ <b>Step 1</b></p> <p><u>Method)</u></p> <p>① Remove the battery of remote controller.</p> <p>② Push the Off Timer and Cancel button simultaneously.</p> <p>③ Insert the battery.</p> <p><u>Result)</u></p> <p>When the display of remote controller is indicated as shown in the right, then go to the step 2.</p>		
<p>※ <b>Step 2</b></p> <p><u>Method)</u></p> <p>If the first digit of remote controller shows "0", go to the step 3.</p> <p>• If it shows 1, press the Mode button one time to change it into 0 and then go to step 3.</p>		
<p>※ <b>Step 3</b></p> <p><u>Method)</u></p> <p>Input the second digit of option code by pressing the High Temp button.</p> <p>example) 021E311422852A311439421F</p> <p><u>Result)</u></p> <p>If 2 is displayed, go to the step 4 (whenever pressing the button, 1~9, A,B,C,D,E,F are lit in order.)</p>		







Operation method	Applicable button	Indicating state
<p><b>*Step 4</b></p> <p><u>Method)</u> Input the third digit of option code by pressing the Low Temp button. example) 02<b>1</b>E311422852A311439421F</p> <p><u>Result)</u> If 1 is displayed, go to the step 5.</p>		
<p><b>* Step 5</b></p> <p><u>Method)</u> Input the fourth digit of option code by pressing the High Fan button. example) 021<b>E</b>311422852A311439421F</p> <p><u>Result)</u> If E displays, go to step 6.</p>		
<p><b>* Step 6</b></p> <p><u>Method)</u> Input the fifth digit of option code by pressing the On Timer button. example) 021E<b>3</b>11422852A311439421F</p> <p><u>Result)</u> If 3 displays, go to step 7.</p>		 <p>SEG5</p>







Operation method	Applicable button	Indicating state
<p><b>* Step 7</b></p> <p><u>Method)</u> Input the sixth digit by pressing the Cancel button. _____ example) 021E3<u>1</u>1422852A311439421F</p> <p><u>Result)</u> If 1 displays, go to step 8.</p>		
<p><b>* Step 8</b></p> <p><u>Method)</u> After completion up to step 7, pressing Mode button. _____</p> <p>① 1~7 steps are saved internally. ② If the first number is 1 at the time, it is correct. So go to step 9. • If wanting to see the screen of 2~7 steps, press the mode button repeatedly to make the first digit 0.</p>		
<p><b>*Step 9</b></p> <p><u>Method)</u> Input the eighth digit by pressing the High Temp button. _____ example) 021E31<u>4</u>22852A311439421F</p> <p><u>Result)</u> If 4 displays, go to step 10.</p>		






Operation method	Applicable button	Indicating state
<p><b>* Step 10</b></p> <p><u>Method)</u> Input the ninth digit by pressing the Low Temp button. example) 021E31142<u>2</u>852A311439421F</p> <p><u>Result)</u> If 2 displays, go to step 11.</p>		
<p><b>*Step 11</b></p> <p><u>Method)</u> Input the tenth digit by pressing the High Fan button. example) 021E31142<u>2</u>852A311439421F</p> <p><u>Result)</u> If 2 displays, go to step 12.</p>		
<p><b>*Step 12</b></p> <p><u>Method)</u> Input the 11st digit by pressing the On Timer button. example) 021E311422<u>8</u>52A311439421F</p> <p><u>Result)</u> If 8 displays, go to step 13.</p>		


Operation method	Applicable button	Indicating state
<p>✳ <b>Step 13</b></p> <p><u>Method)</u> Input the 12th digit by pressing the Cancel button. example) 021E3114228<u>5</u>2A311439421F</p> <p><u>Result)</u> If 5 displays, go to step 14.</p>		
<p>✳ <b>Step 14</b></p> <p><u>Method)</u> After completion up to step 13, pressing Mode button.</p> <p>① Previous steps are saved internally.</p> <p>② If the first number is 2 at the time, it is correct. So go to step 15.</p> <p>• If wanting to see previous screen, press the mode button repeatedly to make the first digit to with digit.</p>		<p>❏ <b>Error</b></p> <p>① If the On/Off, Timer and Fan indicator is flickering, the wrong option code is input. Put off the power of indoor unit and turn it on again and then input the option code again. If the same error occurs, it is the EEPROM is defective or not inserted. Replace the PCB.</p> <p>② If all of On/Off, Timer, Fan and Filter Sign indicator are flickering along with the "Tirring" sound, there is option code already input which are different from the current ones. Check the option code and press the button again if correct. Option code will be input.(Check the option code correctly. At the time, if the same error continues to occur, the option code is out of input range. Check the option code again and repeat the step 1~14.</p>

Operation method	Applicable button	Indicating state
<p><b>* Step 15</b></p> <p><u>Method)</u> Input the 14th digit by pressing the High Temp button. example) 021E311422852<b>A</b>311439421F</p> <p><u>Result)</u> If A displays, go to step 16.</p>		
<p><b>* Step 16</b></p> <p><u>Method)</u> Input the 15th digit by pressing the Low Temp button. example) 021E311422852<b>A3</b>11439421F</p> <p><u>Result)</u> If 3 displays, go to step 17.</p>		
<p><b>* Step 17</b></p> <p><u>Method)</u> Input the 16th digit by pressing the High Fan button. example) 021E311422852<b>A31</b>1439421F</p> <p><u>Result)</u> If 1 displays, go to step 18.</p>		

Operation method	Applicable button	Indicating state
<p><b>* Step 18</b>  <u>Method)</u>            Input the 17th digit by pressing the On Timer button.            example) 021E311422852A311<u>4</u>39421F</p> <p><u>Result)</u>            If 1 displays, go to step 19.</p>		
<p><b>❖ Step 19</b>  <u>Method)</u>            Input the 18th digit by pressing the Cancel button.            example) 021E311422852A311<u>4</u>39421F</p> <p><u>Result)</u>            If 4 displays, go to step 20.</p>		
<p><b>* Step 20</b>  <u>Method)</u>            After completion up to step 20, pressing Mode button.</p> <p>① Previous steps are saved internally.            ② If the first number is 3 of the time, it is correct. so go to step 22.</p> <p>• If wanting to see previous screen, press the mode button repeatedly to make the first digit to with digit.</p>		

Operation method	Applicable button	Indicating state
<p>※ <b>Step 21</b></p> <p><u>Method)</u> Input the 20th digit by pressing the High Temp button. _____ High Temp button. example) 021E311422852A311439<u>4</u>21F</p> <p><u>Result)</u> If 9 displays, go to step 22.</p>		
<p>※ <b>Step 22</b></p> <p><u>Method)</u> Input the 21th digit by pressing the Low Temp button. _____ Low Temp button. example) 021E311422852A3114394<u>2</u>1F</p> <p><u>Result)</u> If 4 displays, go to step 23.</p>		
<p>❖ <b>Step 23</b></p> <p><u>Method)</u> Input the 22th digit by pressing the High Fan button. _____ High Fan button. example) 021E311422852A31143942<u>1</u>F</p> <p><u>Result)</u> If 2 displays, go to step 24.</p>		


Operation method	Applicable button	Indicating state
<p>※ <b>Step 24</b></p> <p><u>Method)</u> Input the 23th digit by pressing the On Timer button. _____ example) 021E311422852A31143942<b>1</b>F</p> <p><u>Result)</u> If 1 displays, go to step 25.</p>		
<p>※ <b>Step 25</b></p> <p><u>Method)</u> Input the 24th digit by pressing the Cancel button. _____ example) 021E311422852A31143942<b>1</b>F</p> <p><u>Result)</u> If F displays, go to step 26.</p>		
<p>※ <b>Step 26</b></p> <p><u>Method)</u> Turn the remote controller toward the indoor unit and press the Power button, and if the "Ting" or "Tirring" sounds, the input of option is completed. _____</p> <p>• If error displays, solve the problem with reference to the right side.</p>		<p>❑ <b>Error</b></p> <p>① If the On/Off, Timer and Fan indicator is flickering, the wrong option code is input. Put off the power of indoor unit and turn it on again and then input the option code again. If the same error occurs, it is the EEPROM is defective or not inserted. Replace the PCB.</p> <p>② If all of On/Off, Timer, Fan and Filter Sign indicator are flickering along with the "Tirring" sound, there is option code already input which are different from the current ones. Check the option code and press the button again if correct. Option code will be input.(Check the option code correctly. At the time, if the same error continues to occur, the option code is out of input range. Check the option code again and repeat the step 1~26.</p>

Operation method	Applicable button	Indicating state
<p>※ <b>Step 27</b>  <b>Method)</b>            If the steps 1 to 26 are completed, remove the battery and insert it again to return to the original display of remote controller.            (Operation mode/SET TEMP.            /fan speed displays.)</p>	 <p>rear side</p>	<p>□ Error</p> <p>① If the On/Off, Timer and Fan indicator is flickering, the wrong option code is input. Put off the power of indoor unit and turn it on again and then input the option code again. If the same error occurs, it is the EEPROM is defective or not inserted. Replace the PCB.</p> <p>② If all of On/Off, Timer, Fan and Filter Sign indicator are flickering along with the "Tirring" sound, there is option code already input which are different from the current ones. Check the option code and press the button again if correct. Option code will be input.(Check the option code correctly. At the time, if the same error continues to occur, the option code is out of input range. Check the option code again and repeat the step 1~26.</p>

### 4-3-3 Setting an indoor unit address and installation option


- ▶ Set the indoor unit address and installation option with remote controller option.  
Set the each option separately since you cannot set the ADDRESS setting and indoor unit installation setting option at the same time. You need to set twice when setting indoor unit address and installation option.
- ▶ Please use the proper wireless remote which can set 24 digit option code. Following is the instructions of setting option code with wireless remote of MR-DH00. (MR-AH01 can be used for operating but cannot be used for setting the installation option because only 12 digit option setting is available.)
- ▶ Please refer to the wired remote installation manual for setting with the wired remote.

#### 4-3-3-1 The procedure of setting option



#### Step 1. Entering mode to set option

1. Remove batteries from the remote controller.
2. Insert batteries and enter the option setting mode while pressing High Temp button and Low Temp button.

3.  Check if you have entered the option setting status.

#### Step 2. The procedure of option setting

After entering the option setting status, select the option as listed below.





Option setting is available from SEG1 to SEG 24

- SEG1, SEG7, SEG13, SEG18 are not need to be set at MR-DH00. They are the page options which were used at the previous other remotes.















































- Set the each 2 bit option code in order except page options.

For example: SEG2, 3 → SEG4, 5 → SEG6, 8 → SEG9, 10 → SEG11, 12 → SEG 14, 15 → SEG 16, 17 → SEG 18, 20 → SEG 21, 22 → SEG23, 24.

















SEG1	SEG2	SEG3	SEG4	SEG5	SEG6	SEG7	SEG8	SEG9	SEG10	SEG11	SEG12
0	X	X	X	X	X	1	X	X	X	X	X
SEG13	SEG14	SEG15	SEG16	SEG17	SEG18	SEG19	SEG20	SEG21	SEG22	SEG23	SEG24
2	X	X	X	X	X	3	X	X	X	X	X

On(SEG1~12)	Off(SEG13~24)
	


### 4-3-3-2 The procedure of setting option











Option setting	Status
<p>1. Setting SEG2, SEG3 option</p> <p>Press Low Fan button(V) to enter SEG2 value.</p> <p>Press High Fan button(^) to enter SEG3 value.</p> <p>Each time you press the button,  →  → ...  →  will be selected in rotation.</p>	  SEG2                      SEG3
<p>2. Setting Cool mode</p> <p> Press Mode button to be changed to Cool mode in the ON status.</p>	
<p>3. Setting SEG4, SEG5 option</p> <p>Press Low Fan button(V) to enter SEG4 value.</p> <p>Press High Fan button(^) to enter SEG5 value.</p> <p>Each time you press the button,  →  → ...  →  will be selected in rotation.</p>	  SEG4                      SEG5
<p>4. Setting Dry mode</p> <p> Press Mode button to be changed to DRY mode in the ON status.</p>	
<p>5. Setting SEG6, SEG8 option</p> <p>Press Low Fan button(V) to enter SEG6 value.</p> <p>Press High Fan button(^) to enter SEG8 value.</p> <p>Each time you press the button,  →  → ...  →  will be selected in rotation.</p>	  SEG6                      SEG8
<p>6. Setting Fan mode</p> <p> Press Mode button to be changed to FAN mode in the ON status.</p>	
<p>7. Setting SEG9, SEG10 option</p> <p>Press Low Fan button(V) to enter SEG9 value.</p> <p>Press High Fan button(^) to enter SEG10 value.</p> <p>Each time you press the button,  →  → ...  →  will be selected in rotation.</p>	  SEG9                      SEG10
<p>8. Setting Heat mode</p> <p> Press Mode button to be changed to HEAT mode in the ON status.</p>	
<p>9. Setting SEG11, SEG12 option</p> <p>Press Low Fan button(V) to enter SEG11 value.</p> <p>Press High Fan button(^) to enter SEG12 value.</p> <p>Each time you press the button,  →  → ...  →  will be selected in rotation.</p>	  SEG11                      SEG12
<p>10. Setting Auto mode</p> <p> Press Mode button to be changed to AUTO mode in the OFF status.</p>	
<p>11. Setting SEG14, SEG15 option</p> <p>Press Low Fan button(V) to enter SEG14 value.</p> <p>Press High Fan button(^) to enter SEG15 value.</p> <p>Each time you press the button,  →  → ...  →  will be selected in rotation.</p>	  SEG14                      SEG15

## The procedure of setting option (cont.)


Option setting	Status
<b>12. Setting Cool mode</b>  Press Mode button to be change to Cool mode in the OFF status.	
<b>13. Setting SEG16, SEG17 option</b> Press Low Fan button(∨) to enter SEG16 value. Press High Fan button(∧) to enter SEG17 value. Each time you press the button, 0 → 8 → ... E → F will be selected in rotation.	  SEG16                  SEG17
<b>14. Setting Dry mode</b>  Press Mode button to be change to Dry mode in the OFF status.	
<b>15. Setting SEG18, SEG20 option</b> Press Low Fan button(∨) to enter SEG18 value. Press High Fan button(∧) to enter SEG20 value. Each time you press the button, 0 → 8 → ... E → F will be selected in rotation.	  SEG18                  SEG20
<b>16. Setting Fan mode</b>  Press Mode button to be change to Fan mode in the OFF status.	
<b>17. Setting SEG21, SEG22 option</b> Press Low Fan button(∨) to enter SEG21 value. Press High Fan button(∧) to enter SEG22 value. Each time you press the button, 0 → 8 → ... E → F will be selected in rotation.	  SEG21                  SEG22
<b>18. Setting Heat mode</b>  Press Mode button to be change to HEAT mode in the OFF status.	
<b>19. Setting SEG23, SEG24 mode</b> Press Low Fan button(∨) to enter SEG23 value. Press High Fan button(∧) to enter SEG24 value. Each time you press the button, 0 → 8 → ... E → F will be selected in rotation.	  SEG23                  SEG24

### Step 3. Check the option you have set

After setting option, press  button to check whether the option code you input is correct or not.

Option	[SEG2,3]	[SEG4,5]	[SEG6,8]	[SEG9,10]	[SEG11,12]
Remote Controller Display					
Option	[SEG14,15]	[SEG16,17]	[SEG18,20]	[SEG21,22]	[SEG23,24]
Remote Controller Display					

### Step 4. Input option

Press operation button  with the direction of remote control for set.  
 For the correct option setting, you must input the option twice.

### Step 5. Check operation

1. Reset the indoor unit by pressing the RESET button of indoor unit or outdoor unit.
2. Take the batteries out of the remote controller and insert them again and then press the operation button.

### 4-3-3-3 Setting an indoor unit address (MAIN/RMC)

1. Check whether power is supplied or not.  
-When the indoor unit is not plugged in, there should be additional power supply in the indoor unit.
2. The panel(display ) should be connected to an indoor unit to receive option.
3. Before installing the indoor unit, assign an address to the indoor unit according to the air conditioning system plan.
4. Assign an indoor unit address by wireless remote controller.  
-The initial indoor unit ADDRESS is set as "MAIN : 0, RMC : 0".  
-Set Main and RMC Address only the setting is required.  
-There is no need to assign the indoor unit Main Address if the outdoor unit is addressing automatically.  
The indoor unit Main address will follow the outdoor unit's automatically.  
-Assign 12 digit when setting the indoor unit address.  
-No need to assign SEG4, 5, 8, 10 which are non applicable. Even though those segments are set, they will be ignored.  
-If you set the applicable segments with numbers other than the indicated, the initial setting will be maintained.

Option No. : 0AXXXX-1XXXXX-2XXXXX-3XXXXX

Option	SEG1		SEG2		SEG3		SEG4	SEG5		SEG6	
Explanation	PAGE		MODE		Setting Main address		RESERVED	RESERVED	The unit digit of an indoor unit		
Indication and Details	Indication	Details	Indication	Details	Indication	Details			Indication	Details	
	0		A		0	No Main address			0~3	A single digit	
					1	Main address setting mode					
Option	SEG7		SEG8		SEG9		SEG10	SEG11		SEG12	
Explanation	PAGE		RESERVED		Setting RMC address		RESERVED	Group channel(*16)		Group address	
Indication and Details	Indication	Details			Indication	Details		Indication	Details	Indication	Details
	1				0	No RMC address		RMC1	0~2	RMC2	0~F
					1	RMC address setting mode					








- When "A"~"F" is entered to SEG5~6, the indoor unit MAIN ADDRESS is not changed.
- If you set the SEG 3 as 0, the indoor unit will maintain the previous MAIN ADDRESS even if you input the option value of SEG6.
- If you set the SEG 9 as 0, the indoor unit will maintain previous RMC ADDRESS even if you input the option value of SEG11~12.

**Example) If you want to set as "MAIN : 3, CHANNEL : 1, RMC : B",**

SEG1	SEG2	SEG3	SEG4	SEG5	SEG6
0	A	1	-	-	3
SEG7	SEG8	SEG9	SEG10	SEG11	SEG12
1	-	1	-	1	B

**assign option codes except SEG 1, 7 which are page options.**



#### 4-3-3-4 Setting an indoor unit installation option (suitable for the condition of each installation location)

1. Check whether power is supplied or not.  
- When the indoor unit is not plugged in, there should be additional power supply in the indoor unit.
2. The panel(display ) should be connected to an indoor unit to receive option.
3. Set the installation option according to the installation condition of an air conditioner.  
- The default setting of an indoor unit installation option is "02000-100000-200000-300000".  
- Individual control of a remote controller(SEG20) is the function that controls an indoor unit individually when there is more than one indoor unit.  
- No need to assign SEG3, 6, 9, 10, 11, 16, 21, 22, 23, 24 which are non applicable. Even though those segments are set, they will be ignored.  
- If you set the applicable segments with numbers other than the indicated, the initial setting will be maintained.
4. Set the indoor unit option by wireless remote controller.

Option No. : 02XXXX-1XXXXX-2XXXXX-3XXXXX

Option	SEG1		SEG2		SEG3		SEG4		SEG5		SEG6	
Explanation	PAGE		MODE		RESERVED		Use of external temperature sensor		Use of central control		RPM setting compensation	
Indication and Details	Indication	Details	Indication	Details			Indication	Details	Indication	Details	0. Not used 1. High ceiling mode 2. High ceiling kit 3. Low noise operation mode	
	0		2				0	Disuse	0	Disuse		
							1	Use	1	Use		
Option	SEG7		SEG8		SEG9		SEG10		SEG11		SEG12	
Explanation	PAGE		Use of drain pump		RESERVED		RESERVED		RESERVED		Master / Slave	
Indication and Details	Indication	Details	Indication	Details							Indication	Details
	1		0	Disuse							0	slave
			1	Use							1	master
			2	Use + 3minute delay								
Option	SEG13		SEG14		SEG15		SEG16		SEG17		SEG18	
Explanation	PAGE		Use of external control		Setting the output of external control		S-Plasma ion		Buzzer control		Number of hours using filter	
Indication and Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details
	2		0	Disuse	0	Thermo on	0	Disuse	0	Use of buzzer	2	1000 Hour
			1	ON/OFF Control	1	Operation on	1	Use	1	Non use of buzzer	6	2000 Hour
			2	OFF Control								

Option	SEG19		SEG20		SEG21	SEG22	SEG23		SEG24
Explanation	PAGE		Individual control of a remote controller		RESERVED	RESERVED	Motion detect sensor		RESERVED
Indication and Details	Indication	Details	Indication	Details			Indication	Details	
	3		0 or 1	Indoor 1			0.No Use (Factory Setting) 1.Standard Mode/Auto Set OFF30 Min. 2.Standard Mode/Auto Set OFF60 Min. 3.Standard Mode/Auto Set OFF 120 Min. 4.Standard Mode/Auto Set OFF 180 Min. 5.Premium Mode/Auto Set OFF30 Min.6.Premium Mode/Auto Set OFF60 Min. 7.Premium Mode/Auto Set OFF 120 Min. 8.Premium Mode/Auto Set OFF 180 Min.		
			2	Indoor 2					
			3	Indoor 3					
			4	Indoor 4					

► If you input a number other than 0~4 on the individual control of the indoor unit(SEG 20), the indoor is set as "Indoor 1".

Example) If you want to set as "Exterior temperature sensor : USE, External control : USE, Number of hours using filter : 2000hr",

SEG1	SEG2	SEG3	SEG4	SEG5	SEG6
0	2	-	1	0	-
SEG7	SEG8	SEG9	SEG10	SEG11	SEG12
1	0	-	-	-	0
SEG13	SEG14	SEG15	SEG16	SEG17	SEG18
2	1	0	-	0	6
SEG19	SEG20	SEG21	SEG22	SEG23	SEG24
3	0	-	-	-	-

assign option codes except SEG 1, 7, 13, 19 which are page options.

#### 4-3-3-5 Changing a particular option

You can change each digit of set option.

Option	SEG1		SEG2		SEG3		SEG4		SEG5		SEG6	
Explanation	PAGE		MODE		The option mode you want to change		The tens' digit of an option SEG you will change		The unit digit of an option SEG you will change		The changed value	
Indication and Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details
	0		D		Option mode	0~F	Tens' digit of SEG	0~9	Unit digit of SEG	0~9	The changed value	0~F



NOTE

- When changing a digit of an indoor unit address setting option, set the SEG3 as 'A'.
- When changing a digit of indoor unit installation option, set the SEG3 as '2'.

Ex) When setting the 'buzzer control' into disuse status.

Option	SEG1	SEG2	SEG3	SEG4	SEG5	SEG6
Explanation	PAGE	MODE	The option mode you want to change	The tens' digit of an option SEG you will change	The unit digit of an option SEG you will change	The changed value
Indication	0	D	2	1	7	1

## OPTION ITEMS

Model	Option Code
NS052SDXEA	011014-1963A2-27343C-370010 020000-100000-200000-300000 03443D-103F44-2443D3-3F4400
NS071SDXEA	014077-1660C8-274750-370000
NS035LDXEA	011037-1361DB-272328-370010 020000-100000-200000-300000 034F46-104C52-24F464-3C5200
NS052LDXEA	011014-1563E6-27343C-370010 020000-100000-200000-300000 034644-104049-246444-304900
NS071LDXEA	014077-1560D9-274750-370000

◆ If you are going to use up to SEG 24, please refer to following instruction.

SEG 17 : 0 1: Using high ceiling kit for 4way.

SEG 18 :

	Not in use	Use
Change temperature display	0(Celsius)	1(Fahrenheit)
Sound Mute	0	2
Mixed operation control	0	4

◆ If you want to use multiple functions, add each of the 'use' value of the function you want to used and input the final addition as option value.(Use Fahrenheit + Sound mute + Mixed operation control : 1 + 2 + 4 = 7)


Ex) 044217-1d00e6-200000-300000

When using Sound mute : 044217-1d00e6-200002-300000

When using high ceiling kit for 4way and mixed operation error preventing function : 044217-1d00e6-200014-300000

## 4-4 Items to be checked first


1. The input voltage should be rating voltage  $\pm 10\%$  range.  
The air conditioner may not operate properly if the voltage is out of this range.
2. Is the link cable linking the indoor unit and the outdoor unit linked properly?  
The indoor unit and the outdoor unit shall be linked by 4 cables.  
Check the terminals if the indoor unit and outdoor unit are properly linked by the same number of cables.  
Otherwise the air conditioner may not operate properly.
3. When a problem occurs due to the contents illustrated in the table below it is a symptom not related to the malfunction of the air conditioner.

No	Operation of air conditioner	Explanation
1	In a COOL operation mode, the compressor does not operate at a room temperature higher than the setting temperature that the INDOOR FAN should operate. <b>[In case of heat pump model]</b> In a HEAT operation mode, the compressor does not operate at a room temperature lower than the setting temperature that indoor fan should operate.	In happens after a delay of 3 minutes when the compressor is reoperated. The same phenomenon occurs when a power is on. As a phenomenon that the compressor is reoperated after a delay of 3 minutes, the indoor fan is adjusted automatically with reference to a temperature of the air blew.
2	Compressor stops operation intermittently in DRY(  ) mode.	Compressor operation is controlled automatically in DRY mode depending on the room temperature and humidity.
3	<b>[In case of heat pump model]</b> Compressor of the outdoor unit is operating although it is turned off in a HEAT mode.	When the unit is turned off while de-ice is activated, the compressor continues operation for up to 12 minutes(maximum) until the deice is completed.
4	<b>[In case of heat pump model]</b> The compressor and indoor fan stop intermittently in HEAT mode.	The compressor and indoor fan stop intermittently if room temperature exceeds a setting temperature in order to protect the compressor from overheated air in a HEAT mode.
5	<b>[In case of heat pump model]</b> Indoor fan and outdoor fan stop operation intermittently in a HEAT mode.	The compressor operates in a reverse cycle to remove exterior ice in a HEAT mode, and indoor fan and outdoor fan do not operate intermittently for within 20% of the total heater operation

## 4-5 Fault Diagnosis by Symptom

### 4-5-1 No Power(completely dead) - Initial diagnosis

1. Checklist:
  - 1) Is Power source voltage normal?
  - 2) Is AC power linked correctly?( miss-wiring, wire detaching etc. )
  - 3) Is any LED on the MAIN PCB of Outdoor unit lit?
  - 4) Is terminal voltage for indoor unit normal?(230Vac nominal)
  - 5) Is Wired remote controller installed correctly?
2. Troubleshooting procedure




## 4-5-2 The Outdoor unit Power Supply error

### 1. Checklist:

- 1) Are the input power voltage and power connection correct?
- 2) Is there any Fuse Short of the indoor or outdoor unit?
- 3) Is any LED lit on both MAIN PCB and INVERTER PCB?
- 4) Are Reactor wires of the outdoor unit connected correctly?

### 2. Troubleshooting procedure




## 4-5-3 The Outdoor unit Fan error

### 1. Checklist:

- 1) Are the input power voltage and power connection correct?
- 2) Is the motor wire connected to the outdoor PCB correctly?
- 3) Is there no obstacle at the surrounding of motor and propeller?
- 4) Does the driver in the motor case broken?

### 2. Troubleshooting procedure



# TEST operation #  
press K900 button on the  
MAIN PCB after power on.


- once : cooling mode  
- twice in a second :  
heating mode

#### 4-5-4 Total current trip error

1. Checklist :


- 1) Is the input power voltage proper?
- 2) Is the refrigerant charged properly?
- 3) Does the compressor rotate normally?(Reverse rotation, Locking etc.)
- 4) Does the outdoor fan operate normally?(Fan propeller loss, Motor error ect.)
- 5) Is the installation condition of outdoor unit good?(Piping, Space etc.)
- 6) Is there no ventilation obstruction at the surrounding of outdoor unit?(Outdoor unit cover, Fan front obstruction etc.)
- 7) Is there no ventilation obstruction at the surrounding of indoor unit?(Overload condition in heating mode)

2. Troubleshooting procedure




## 4-5-5 In case of heating at the cooling mode or cooling at the heating mode

### 1. Troubleshooting procedure



## In case of heating at the cooling mode or cooling at the heating mode(cont.)





## 4-5-6 Outdoor temperature sensor error

### 1. Checklist :

- 1) Is the sensor connector connected correctly?
- 2) Is the sensor placed correctly?
- 3) Does the both terminal of sensor satisfy the resistance value in accordance with temperature?
- 4) Is the resistance value of sensor connection pull\_up correct?

### 2. Troubleshooting procedure





## 4-5-7 Discharge temperature sensor error

### 1. Checklist :

- 1) Is the sensor connector connected correctly?
- 2) Is the sensor placed correctly?
- 3) Does the both terminal of sensor satisfy the resistance value in accordance with temperature?
- 4) Is the resistance value of sensor connection pull\_up correct?

### 2. Troubleshooting procedure





## 4-5-8 Coil temperature sensor error

### 1. Checklist :

- 1) Is the sensor connector connected correctly?
- 2) Is the sensor placed correctly?
- 3) Does the both terminal of sensor satisfy the resistance value in accordance with temperature?
- 4) Is the resistance value of sensor connection pull\_up correct?

### 2. Troubleshooting procedure




## 4-5-9 Fan error

### 1. Checklist :

- 1) Isn't the fan locked?
- 2) Is the sensor placed correctly?
- 3) Does the both terminal of sensor satisfy the resistance value in accordance with temperature?
- 4) Is the resistance value of sensor connection pull\_up correct?

### 2. Troubleshooting procedure




## 4-5-10 DC-Link voltage sensor error

### 1. Checklist :

- 1) Is the connection of R, S, T power wire normal?
- 2) Are Relay RY21 and R200 on the INVERTER PCB mounted normally?

### 2. Troubleshooting procedure




## 4-5-11 O.C.(Over Current) error

### 1. Checklist :

- 1) Is the refrigerant charged properly?
- 2) Does the compressor rotate normally?(Reverse rotation, Locking etc.)
- 3) Is connection of compressor wire normal?
- 4) Is compressor motor normal?(Insulation, Coil resistance etc.)
- 5) Does a temporary cycle overload condition happened?

### 2. Troubleshooting procedure




## 4-5-12 Communication error

### 1. Checklist :

- 1) Is the communication cable between the indoor unit and outdoor unit connected correctly?
- 2) Isn't the power cable and communication cable wiring error?

### 2. Troubleshooting procedure




## 4-5-13 Compressor start error

### 1. Checklist :


- 1) Is the connection of cable for the compressor and power?
- 2) Is the interphase resistance of compressor normal?

### 2. Troubleshooting procedure



## 4-5-14 Compressor lock error

1. Checklist :
  - 1) Is the connection of cable for the compressor and power?
  - 2) Is the interphase resistance of compressor normal?
2. Troubleshooting procedure




## 4-5-15 DC Link Over voltage/ Low voltage error

### 1. Checklist :

- 1) Is the power voltage normal?(Lightning, Power interruption etc.)
- 2) Is AC Power cable connection normal?(Detaching the wire)

### 2. Troubleshooting procedure



## 4-5-16 The others

1. Capacity miss match
  - Check again the indoor unit option code.

## 4-6 PCB Inspection Method

### 4-6-1 Pre-inspection Notices

1. Turn off the breaker, AC power source, before disassembling the unit because of electrical hazard.
2. Confirm the complete discharge of capacitor C102, C702, C703, C704, C705, C706, C707 on the INVERTER PCB when you touch the PCB. Especially discharging speed of C702-C707 is very slow because of little load in stand-by condition. To confirm the voltage of C702-C707, measure the DC link voltage at the IGBT module pins near C701 at which applying voltage (450-510Vdc) is marked.  
To confirm discharging of C102, measure the voltage of non mounted C103 solder hole or check if all LEDs are off.
3. Don't touch the metal body of electrolytic capacitor for avoiding electrical shock before confirming discharge.
4. To discharging the capacitor use power resistor of about 1 Kohm 10W. Soldering tool (non electronic temperature control type) can be used as a discharging resistor.
5. Don't pull the lead wire but hold the whole housing to disconnect or connect a housing from or to the PCB.

### 4-6-2 Inspection Procedure

1. Check the connection of each housing to the connector first and the peeling of PCB copper pattern.
2. The PCB is composed of the 3 part in the indoor unit.
  - INDOOR Main PCB part : Indoor unit control, MICOM and surrounding circuit, relay, fan motor driving circuit, sensor reading circuit, buzzer driving circuit and DC power supplying circuit.
  - Display PCB part : LED lamps, Switch, Remocon module.
  - INDOOR EMI PCB part : Line filter, Noise Capacitor and Varistor
3. The PCB is composed of the 3 part in the outdoor unit.
  - EMI PCB part : Line filter for electrical noise, Varistors for surge and Fuses.
  - MAIN PCB part : Refrigeration cycle controller with MICOM
  - INVERTER PCB part : Compressor driving inverter and BLDC fan controller

### 4-6-3 Indoor Detailed Inspection Procedure

No	Procedure	Inspection Method	Cause
1	Open the electronic component box and check the PCB fuse	Turn off the power 1) Is the Fuse F701 on the EMI PCB blown? 2) Is the Fuse F702 on the MAIN PCB blown?	<ul style="list-style-type: none"><li>• Over current</li><li>• Indoor fan motor short</li><li>• PCB AC Part pattern short</li></ul>
2	Check the LEDs for DC power and communication condition	Turn on the power 1) Is RED LED blinking? his led means micom is running normally. 2) Is GREEN LED blinking? This means communication between Indoor and Outdoor unit is on 3) Is YELLOW LED blinking? This means communication between Indoor and wired remote controller is on. It may take one minute to start communication	<ul style="list-style-type: none"><li>• Communication circuit trouble</li><li>• Communication wire connection trouble</li><li>• wrong connection for power supply wire of remote controller</li></ul>
3	Check the DIP and rotary switch on the PCB	1) Is the setting of each switch proper?	<ul style="list-style-type: none"><li>• Wrong setting of switch</li></ul>
4	Check the DC voltage	1) Is the voltage of CN32 pin #1-#2 12V? 2) Is the voltage of C109 V?	<ul style="list-style-type: none"><li>• SMPS on MAIN PBA trouble</li><li>• Load short</li></ul>
5	FAN operation checking Press the ON/OFF button. 1. FAN Speed[HIGH] 2. FAN mode	1) Is the FAN motor running? 2) Is the connection of CN73 normal?	<ul style="list-style-type: none"><li>• Controller trouble inside of the fan motor</li><li>• connector trouble of CN73</li></ul>

## 4-6-4 Outdoor Detailed Inspection Procedure


No	Procedure	Inspection Method	Cause
1	Turn OFF the power and check wire and socket connection on each part	Wait until C702-C707 discharged 1) Is connection of housing to socket normal? 2) Is connection of each wire to terminal block normal? 3) Is the reactor wire connection normal? 4) Is there no miss-wiring of each cable?	<ul style="list-style-type: none"> <li>• installation mistake</li> <li>• miss assembling</li> </ul>
2	FUSE check	Is the fuses on each PCB normal? 3 fuses on EMI PCB 1 fuse on MAIN PCB 1 fuse on INVERTER PCB	<ul style="list-style-type: none"> <li>• wire short</li> <li>• overload</li> <li>• BLDC FAN short error</li> </ul>
3	Turn on the power and check voltage of terminal block	Is N-R,N-S,N-T around 230Vac? Is R-S,S-T,T-R around 400Vac? Is L-N(to indoor unit) around 230Vac? Is F1-F2 within 5Vdc?	<ul style="list-style-type: none"> <li>• miss wiring of power cable</li> <li>• wire detaching</li> </ul>
4	Check LED display on AIN PCB	1) Is RED LED ON? 2) Is GREEN LED Blinking once a second? 3) Is LEDs displaying error code pattern?	<ul style="list-style-type: none"> <li>• MAIN PCB power trouble</li> <li>• bad communication between indoor and outdoor unit</li> <li>• error detection</li> </ul>
5	Check LED display on INVERTER PCB	1) Is RED LED ON? 2) Is GREEN LED Blinking once a second? 3) Is LEDs displaying error code pattern?	<ul style="list-style-type: none"> <li>• INVERTER PCB power trouble</li> <li>• NO communication between MAIN and INVERTER PCB</li> <li>• error detection</li> </ul>
6	Check DC voltage of SMPS output	<b>MAIN PCB</b> 1) Is voltage of CN51 pin#1-#2 12-14.5V? 2) Is voltage of C108 5V?  <b>INVERTER PCB</b> 3) Is voltage of CN51 pin#1-#2 5V? 4) Is voltage of C124 12V? 5) Is voltage of each ZD100,ZD101,ZD102,ZD103 17-18V?	<ul style="list-style-type: none"> <li>• SMPS circuit trouble</li> </ul>
7	Check INVERTER PCB	1) Is resistance of R100 200ohm? To check this, touch one probe to CN10 pin#1(N) and the other to D101 upper side pin of '~' marking pins 2) Is DC Link voltage 450-510V? Check IGBT module pins marking voltage near C701	<ul style="list-style-type: none"> <li>• resister</li> <li>• wire connection between EMI PCB and INVERTER PCB</li> </ul>
8	Check BLDC fan	1) See 12-2-3 The Outdoor unit Fan error(Fault Diagnosis)	

## 4-7 Main Part Inspection Method

Part	Breakdown Inspection Method				
Indoor Unit Temperature Sensor	Measure sensor resistance with a multimeter				
	Normal	At the normal temperature 37kΩ~8.3kΩ(-7°C~+30°C)			
	Abnormal	∞,0Ω...Open or Short			
Indoor Unit BLDC FAN Motor	Measure terminal resistance with a multimeter				
	Normal	At the normal temperature(10°C~30°C)			
		wire	pin number	Resistance	Remark
		RED - BLACK	1-3	over 1MΩ	+300V motor power
		WHITE - BLACK	4-3	1KΩ ~ 2KΩ	+15V control power
		YELLOW - BLACK	5-3	200KΩ ~ 300KΩ	control
BLUE - BLACK		6-3	10KΩ ~ 50KΩ	pulse	
Abnormal	∞,0Ω...Open or Short				
Outdoor Unit Outdoor Temperature Sensor & Cond Temperature Sensor	Measure sensor resistance with a multimeter				
	Normal	At the normal temperature 37kΩ~8.3kΩ(-7°C~+30°C) see 12-2-6 and 12-2-8			
	Abnormal	∞,0Ω...Open or Short			
Outdoor Unit Discharge Temperature Sensor	Measure sensor resistance with a multimeter				
	Normal	At the normal temperature 563kΩ~157kΩ(0°C~+30°C) see 12-2-7			
	Abnormal	∞,0Ω...Open or Short			
Outdoor Unit BLDC FAN MOTOR	Measure terminal resistance with a multimeter				
	Normal	At the normal temperature(10°C~30°C)			
		wire	pin number	Resistance	Remark
		RED - BLACK	1-3	over 1MΩ	+300V motor power
		WHITE - BLACK	4-3	1KΩ ~ 2KΩ	+15V control power
		YELLOW - BLACK	5-3	200KΩ ~ 300KΩ	control
BLUE - BLACK		6-3	10KΩ ~ 50KΩ	pulse	
Abnormal	0Ω...Open or Short				
Outdoor Unit 4way Valve Solenoid	Measure resistance with a multimeter				
	Normal	At the normal temperature(10°C~30°C) 1.6KΩ±15%			
	Abnormal	∞,0Ω...Open or Short			

## 5. PCB Diagram and Parts List


### 5-1 INDOOR MAIN PCB



①	Floating S/W : SMW250-02(BLK)	⑬	Wired Remote Controller Communication : YW396-02(BLU)
②	Indoor Pipe In Temperature Sensor : SMW250-04(WHT) Indoor Room Temperature Sensor : SMW250-04(WHT)	⑭	Option Load Connector : SMW250-05(YEL)
③	Indoor Pipe Out : SMW250-02(WHT) Temperature Sensor : SMW250-02(WHT)	⑮	Heater : YW39607AV(WHT)
④	Heater Discharge : SMW250-02(YEL) Temperature Sensor : SMW250-02(YEL)	⑯	Indoor Address S/W
⑤	Wired Remote Controller Power : YW396-02(WHT)	⑰	Indoor Option S/W
⑥	External Control(S/W Part) : SMW250-02(RED)	⑱	Indoor Fan(TAP) : YW396-09AV(WHT)
⑦	EEV : SMW250-05(BLU) : SMW250-05(BLU)	⑲	Ventilator : YW396-03AV(BLK)
⑧	Display : SMW200-11(WHT) : SMW200-11(WHT)	⑳	Drain Pump : YW396-03AV(YEL)
⑨	External Control(Display Part) : SMW250-04(RED)	㉑	Hot Coil : YW396-03AV(RED)
⑩	HALL IC : SMW250-03(BLU)	㉒	Indoor Fan(SSR) : YW396-03AV(RED)
⑪	MICOM Download : SMW200-10(WHT)	㉓	Power : YW396-03AV(WHT)
⑫	Indoor/Outdoor Communication : YW396-02(RED)	㉔	Transformer Out : YW396-03AV(WHT)
		㉕	Main Power In : YW396-03AV(BLU)
			Power : YW396-03AV(BLU)
			Transformer In : SMW250-03(RED)

This Document can not be used without Samsung's authorization.


## 5-2 OUTDOOR MAIN PCB



①	OLP /COND THERMISTOR CONNECTOR	SMAW250A-04 WHT
②	OUT/DISCHARGE THERMISTOR CONNECTOR	SMAW250A-04 RE
③	BLDC-FAN CONNETCOR	YAN396-06V WHT
④	EEV-A CONNECTOR	SMAW250A-05 RED
⑤	DISPLAY CONNECTOR	SMW200-10 NTR
⑥	DISPLAY CONNECTOR	SMAW250A-03 RED
⑦	PC DOWNLOADCONNECTOR	SMW200-10 BLK
⑧	S N E T CONNECTOR	SMW200-04 NTR
⑨	AS-PRO DOWNLOAD CONNECTOR	SMAW200A-07 WHT
⑩	DISPLAY CONNE CTORS	MW200-05 NTR
⑪	DOWNLOAD-INV CONNECTOR S	MW200-10 RED

This Document can not be used without Samsung's authorization.

## ■ 5-3 OUTDOOR SUB PCB




①	12V POWER CONNECTOR	YW396-02V BLU
②	MAIN -SUB SIGNAL CONNECTOT	SMW250-04 WHT
③	MAIN -SUB SIGNAL CONNECTOT	SMW200-15NTR

This Document can not be used without Samsung's authorization.


## 6. Wiring Diagram

### 6-1 Indoor Unit




This Document can not be used without Samsung's authorization.

■ Outdoor Unit :RC035DHXEA/ RC052DHXEA



## Outdoor Unit : RC071DHXEA




This Document can not be used without Samsung's authorization.

# 7.Schematic Diagram

## 7-1 Indoor Unit


### ■ MAIN PCB



This Document can not be used without Samsung's authorization.

7-2 OUTDOOR UNIT PCB


7-2 -1 MAIN PCB (RC071DHXEA)



This Document can not be used without Samsung's authorization.

## 7-2 OUTDOOR UNIT PCB


### 7-2-2 SUB PCB (RC071DHXEA)



This Document can not be used without Samsung's authorization.


7-2 OUTDOOR UNIT PCB

7-2-3 MAIN PCB (RC035/052DHXEA)



This Document can not be used without Samsung's authorization.

#### 7-2-4 SUB PCB (RC035/052DHXEA)




---

7-5

## 8. Preference Sheet

### 8-1 Refrigerating Cycle Diagram



#### ■ CONDENSER

High temperature and high pressure gas state coolant discharged from the compressor is converted to a liquid state as it is cooled down by the heat emission in the outdoor condenser unit, and sent to the evaporator.

#### ■ COMPRESSOR

Low temperature and low pressure coolant is compressed and sent to the cycling system

■ **EVAPORATOR** Liquid coolant sucked in through the capillary tubes cools down the room by absorbing the surrounding heat as it evaporates (converting from liquid to gas). (Absorbing heat required for evaporation)

#### ■ SERVICE VALVE

You can open the valve by turning the need valve counterclockwise using hex wrench, and it is used for vacuum, gas purging, coolant injection, coolant purging, and indoor-outdoor unit connection.

#### ■ ACCUMULATOR

Accumulator prevents the flow of liquid-state coolant into the compressor. (Liquid-state coolant flowing into the compressor will overload the compressor.)

## 8-2 Index of Model Name

### Outdoor Unit Model Code

<b>RC</b>	<b>140</b>	<b>D</b>		<b>H</b>	<b>X</b>	<b>E</b>	<b>A</b>	<b>/</b>	-	-	-
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)		Buyer code		

(1) Product Type		
<b>R</b>	D	DVM
	J	FJM
	C	SINGLE(CAC)

(2) Capacity	
HP / KW / BTU / TON	

(3) Chassis	
P	Inverter RPM
D	Inverter DLX
S	Inverter DLX
F	Constant rate (value)
X	Constant rate (tender)
Z	Flagship
T	Tower (Top Discharge)
U	Ice box

(4) Separator		
1	1WAY	CST
2	2WAY	
M	MINI 4 WAY	
4	4WAY	
H	High Static Pressure	DUCT
S	Middle Static Pressure	
L	Low Static Pressure	
C	CEILING	CONV
J	CONSOLE	
F	PAC	
P	FAC	

(5) MODE	
C	C/O
H	H/P
E	H/P+HEATER
G	C/O+HEATER
T	TROPICAL C/O
Q	TROPICAL H/P

(6) Refrigerant	
R22	R
R410A	X

(7) Power Supply	
Normal	N
115V,60Hz	A
220V,60Hz	B
208~230V,60Hz	C
200~220V,50Hz	D
220~240V,50Hz	E
208~230V,60Hz,3Φ	F
380~415V,50Hz,3Φ	G
127V, 50Hz	M
380V/60Hz,3Φ	H
460V,60Hz,3Φ	J

(8) VERSION	
1~9	KOREAN
A~Z	EXPORT

### Indoor Unit Model Code

<b>NS</b>	<b>071</b>	<b>L</b>	<b>D</b>	<b>X</b>	<b>E</b>	<b>A</b>	<b>/</b>	-	-	-
(1)	(2)	(3)	(4)	(5)	(6)	(7)		Buyer code		

(1) Product Type		
<b>N</b>	D	DVM
	J	FJM
	M	MULTI
	S	SINGLE(CAC)
	H	Hydro-Box

(2) Capacity	
HP / KW / BTU / TON	

(3)Chassis		
1	1WAY	CST
2	2WAY	
M	MINI 4 WAY	
4	4WAY	
H	High Static Pressure	DUCT
S	Middle Static Pressure	
L	Low Static Pressure	
C	CEILING	CONV
J	CONSOLE	
F	PAC	
P	FAC	
B	Mont Blabc	RAC
V	VIVACE	
Q	NEO-FORTE(EEV)	
N	NEO-FORTE	

(4) MODE	
C	C/O
H	H/P
T	Tender
V	Value

When grade classification is necessary	
Z	H/P (Flagship)
P	H/P (Premium)
D	H/P (Deluxe)
S	H/P (Standard)
CP	H/P (Premium)

(5) Refrigerant	
R22	R
R410A	X

(6) Power Supply	
Normal	N
115V,60Hz	A
220V,60Hz	B
208~230V,60Hz	C
200~220V,50Hz	D
220~240V,50Hz	E
208~230V,60Hz,3Φ	F
380~415V,50Hz,3Φ	G
127V, 50Hz	M
380V/60Hz,3Φ	H
460V,60Hz,3Φ	J

(7) VERSION	
1~9	KOREAN
A~Z	EXPORT
Z	The Z version is a high-efficiency EEV Mode indoor unit.



#### **GSPN(Global Service Partner Network)**

Area	Web Site
Europe	<a href="http://gspn1.samsungcsportal.com">http://gspn1.samsungcsportal.com</a>
CIS	<a href="http://gspn1.samsungcsportal.com">http://gspn1.samsungcsportal.com</a>
Mideast & Africa	<a href="http://gspn1.samsungcsportal.com">http://gspn1.samsungcsportal.com</a>
Asia	<a href="http://gspn2.samsungcsportal.com">http://gspn2.samsungcsportal.com</a>
North America	<a href="http://gspn3.samsungcsportal.com">http://gspn3.samsungcsportal.com</a>
Latin America	<a href="http://gspn3.samsungcsportal.com">http://gspn3.samsungcsportal.com</a>
China	<a href="http://china.samsungportal.com">http://china.samsungportal.com</a>

This Service Manual is a property of Samsung Electronics Co., Ltd.  
Any unauthorized use of Manual can be punished under applicable  
International and/or domestic law.

© Samsung Electronics Co., Ltd. 2012.  
Printed in China.  
Code No. DB98-33563A-2